













## I-VALO LUKA INSTALLATION INSTRUCTIONS




LB100




LB220

0° / 5° / 10° / 15° / 25°




LB200

0° / 5° / 10° / 15° / 25°




LB210

0° / 5° / 10° / 15° / 25°




LB300

0° / 15° / 25° / 35° / 45°




LB310

0° / 15° / 25° / 35° / 45°



LB320



LB400

0°-125°

