






## I-VALO ARVO INSTALLATION INSTRUCTIONS




**FI** Tämä tuote sisältää valonlähteen, jonka energiatehokkuusluokka on **A**.  
**EN** This product contains a light source of energy efficiency class **A**.  
**DE** Dieses Produkt enthält eine Lichtquelle der Energieeffizienzklasse **A**.  
**SV** Denna produkt innehåller en ljuskälla med energieffektivitetsklass **A**.  
**FR** Ce produit contient une source lumineuse de classe d'efficacité énergétique **A**.  
**PL** Ten produkt zawiera źródło światła o klasie efektywności energetycznej **A**.




2a

Max. Ø4,8mm




2b



3a

~1


	GNYE
N	BU
L	BN



3b

~1 + DALI


	PE
N	N
1	L
2	D1
3	D2




3c

~3


	PE
N	N
1	L
2	L2
3	L3




4a




4b




4c



5



6



7

